


Cum sa alegem aparatul de gard electric potrivit?

Cai	Input	1 la 5 km	5 la 10 km	10 la 20 km	20 la 50 km	Peste 50 km
	9V	ECO9 SILVER	OCEAN	-	-	-
	12V	BERGER 12 MASTER 12 SC 25	BERGER 30 MASTER 30 SC 70 MASTER 30/230 H30	BERGER 30-40 MASTER 30-40 H30 H32	BERGER 40 MASTER 40 H32	MASTER 50 H42
	220V	SEC 1500 EASYCLOT	SEC 3000	SEC 5000 SEC 10 000	SEC 10 000 SEC 15 000	SEC 15 000

Vaci	Input	1 la 5 km	5 la 10 km	10 la 20 km	20 la 50 km	Peste 50 km
	9V	ECO9 SILVER	OCEAN	-	-	-
	12V	BERGER 30 MASTER 30 SC 25	BERGER 30-40 MASTER 30-40 SC 70 H30 MASTER 30/230	BERGER 40 MASTER 40 H32	BERGER 40 MASTER 50 H32 H42	MASTER 50 H42
	220V	SEC 3000	SEC 10 000	SEC 10 000 SEC 15 000	SEC 15 000 BUFFALO F8	BUFFALO F10-F15

Mistreti, lupi si alte animale salbatice	Input	1 la 5 km	5 la 10 km	10 la 20 km	20 la 50 km	Peste 50 km
	9V	OCEAN	-	-	-	-
	12V	BERGER 30 MASTER 30 MASTER 30/230 H30	BERGER 30-40 MASTER 30-40 MASTER 30/230 H32	MASTER 50 H42	-	-
	220V	SEC 3000	SEC 10 000	SEC 10 000 SEC 15 000	SEC 15 000 BUFFALO F8	BUFFALO F10-F15

Oi, capre, porci	Input	1 la 5 km	5 la 10 km	10 la 20 km	20 la 50 km	Peste 50 km
	9V	ECO 9 SILVER	OCEAN	-	-	-
	12V	BERGER 30 MASTER 30 MASTER 30/230 H30	BERGER 30-40 MASTER 30-40 MASTER 30/230 H32	BERGER 40 MASTER 40 H32	MASTER 50 H42	-
	220V	SEC 3000	SEC 10 000	SEC 10 000 SEC 15 000	SEC 15 000 BUFFALO F8	BUFFALO F10-F15

Caini, pisici	Input	1 to 5 km	5 to 10 km
	9V	ECO 9 SILVER	OCEAN
	12V	MASTER 12 BERGER 12 SC 25 MASTER 30/230 H30	MASTER 30 BERGER 30 SC 70 MASTER 30/230 H30
	220V	EASYCLOT SEC 1500	SEC 1500 SEC 3000



Cum sa instalam gardul?

Distanta intre pamant si firele de gard electric / tensiunea minima pe capatul gardului

